
EE3230 Lecture 2: CMOS Processing Technology

Ping-Hsuan Hsieh (謝秉璇)

Delta Building R908

EXT 42590

phsieh@ee.nthu.edu.tw

Outline

- **CMOS Technology**
- Layout Design Rules
- CMOS Process Enhancements
- Technology-related CAD Issues
- Manufacturing Issues


CMOS Technologies

- n-well process: p-substrate
- p-well process: n-substrate
- Twin-well process
 - Optimized for each transistor type
- Triple-well process (deep n-well)
 - Good isolation between analog and digital blocks
- BiCMOS process (SiGe)
- Silicon-on-insulator (SOI) process



Process Steps

- Wafer formation
- Photolithography
- Well and channel formation
- Isolation
- Gate oxide
- Gate & source/drain formation
- Contacts and metalization
- Passivation


Schematic and Layout of CMOS Inverter




Cross Section of CMOS Inverter




Photomasks of n-well CMOS Inverter




(a) n Well




(b) Active region




(c) Poly 1




(d) $n+$ Diffusion




(e) $p+$ Diffusion



(f) Contact hole




(g) Metal 1



n-well CMOS Process (I)


(a) (mask #1)

Define n-well diffusion




(b) (mask #2)

Define active regions (think oxide)




(c)

LOCOS oxidation(field oxide)




(d) (mask #3)

Polysilicon gate




n-well CMOS Process (II)


(e) (mask #4)
***n*+ diffusion**




(f) (mask #5)
***p*+ diffusion**




(g) (mask #6)
Contact holes




(h) (mask #7)
Metalization



Cross-Sectional Diagram of MOSFET




Photolithography



- Greek: *Photo*(light)+*lithos*(stone)+*graph*(picture)
 - Carving pictures into stone using light
- Resolution enhancement techniques
 - **Optimal proximity correction (OPC)**: local pre-distortion, **phase shift masks (PSM)**: light diffraction, **off-axis illumination: (OAI)**, contrast enhancement of repetitive pattern

Well and Channel Formation




- Vary portions of donor (n) and acceptor (p)
 - Epitaxy: single-crystal film growth
 - Deposition: chemical vapor deposition + drive-in
 - Implantation: ion implantation + diffusion + annealing (standard well and source/drain definition)

Silicon Dioxide (SiO₂)


- Wet oxidation
 - Oxidizing atmosphere contains water vapor
temp: 900~1000°C, quick for thick field oxide
- Dry oxidation
 - Oxidizing atmosphere is pure oxygen
temp: ~1200°C, highly controlled thin gate oxide
- Atomic layer deposition
 - Thin chemical layer deposition for various requirement
(SiO₂, metal, dielectric)

Isolation: LOCOS




- Local Oxidation of Silicon (LOCOS)
 - Low density, high electrical field: bird's beak shape


Isolation: STI




(a) Trench Etch



(b) Liner Oxidation



(c) Fill Trench with Dielectric





(d) CMP for Planarization

- Shallow Trench Isolation (STI)
 - High density and better isolation, need chemical mechanical polishing (CMP) to planarize the structure


Gate Oxide

- Shorter gate length
→ thinner gate oxide
- Effective Oxide Thickness (EOT)
 - Decrease EOT using stack gate structure with high- k dielectric
- Dual gate oxide for core and I/O




Existing 90 nm Process
Capacitance = 1 x
Leakage Current = 1 x

$$C = \frac{\kappa \epsilon_0 A}{t}$$



A potential high- k process
Capacitance = 1.6 x
Leakage Current = 0.01 x




Gate & Source/Drain Formation




- Self-aligned poly-silicon (poly) gate
- Lightly doped drain (LDD) structure

LDD & Salicide


- LDD
 - Reduce electrical field of drain junction and hot-electron damage
 - High sheet resistance
- Salicide:
self-aligned silicide
 - Refractory metal to reduce interconnection resistance of gate, source/drain
- CMP
 - Structure planarization for further stack process



Contacts and Metalization



- Contact
 - Poly-to-metal
 - diffusion-to-metal
- VIA
 - Metal-to-metal
- CMP
 - Structure planarization
 - for further stacking processes



Outline



- CMOS Technology
- **Layout Design Rules**
- CMOS Process Enhancements
- Technology-related CAD Issues
- Manufacturing Issues

Layout Design Rules (I)


- Design rule: geometric constraint and tolerance for high probability of correct fabrication
 - Feature size, separations, and overlaps
- Well rule: isolation
- Transistor rule: channel quality
 - Poly, active region, n+/p+ implant
- Contact rule: single size for precise process control
- Metal and VIA rule: productivity and conductivity
 - Top metal with wider size, space and VIA rules

Layout Design Rules (II)

- N-well process transistors



Layout Design Rules (III)



Layout Design Rules (IV)

Table 3.3 Micron design rules for 90nm process			
Layer	Rule	Description	90 nm rule (μm)
Well	1.1	Width	0.75
	1.2	Spacing to well at different potential	1.5
	1.3	Spacing to well at same potential	1.0
Active (diffusion)	2.1	Width	0.15
	2.2	Spacing to active	0.20
	2.3	Source/drain surround by well	0.25
	2.4	Substrate/well contact surround by well	0.25
	2.5	Spacing to active of opposite type	0.30
Poly	3.1	Width	0.09
	3.2	Spacing to poly over field oxide	0.15
	3.2a	Spacing to poly over active	0.15
	3.3	Gate extension beyond active	0.15
	3.4	Active extension beyond poly	0.15
	3.5	Spacing of poly to active	0.10
Select	4.1	Spacing from substrate/well contact to gate	0.25
	4.2	Overlap of active	0.20
	4.3	Overlap of substrate/well contact	0.10
	4.4	Spacing to select	0.30
Contact (to poly or active)	5.1, 6.1	Width (exact)	0.12
	5.2b, 6.2b	Overlap by poly or active	0.01
	5.3, 6.3	Spacing to contact	0.15
	5.4	Spacing to gate	0.10

Outline


- CMOS Technology
- Layout Design Rules
- **CMOS Process Enhancements**
- Technology-related CAD Issues
- Manufacturing Issues

CMOS Process Enhancements


- Multiple threshold voltage and oxide thickness
 - Low core voltage for low power
 - High I/O voltage for interface compatibility
- Silicon on Insulator: higher speed
- High- k gate dielectric: thinner EOT
- Higher mobility: SiGe BJT, strained silicon
- Low-leakage transistor: finFET, gate-all-around (GAA)
- Plastic transistor: flexible electronic paper
- High-voltage transistor: LCD driver, power electronics
- Copper interconnect: high conductivity
- Low- k dielectric: low wire capacitance

Silicon on Insulator


- Pros
 - No capacitance between source/drain and body
→ higher speed
 - No latch-up




- Cons
 - Floating body
→ history effect
 - Self-heating effect
 - Parasitic BJT
→ pass-gate leakage




High- k and Higher Mobility



SiGe bipolar transistor



Strained Silicon




High- k + metal gate



Modern CMOS scaling is as much about material and structure innovation as dimensional scaling

Mark Bohr, "The new ear of scaling in an SoC world," plenary session, ISSCC 2009

FinFET and GAA Structure




- Multi-gate FETs
 - + Improved electrostatics
 - + Steeper sub-threshold slope
 - ? Higher parasitic resistance
 - ? Higher parasitic capacitance




Mark Bohr, "The new era of scaling in an SoC world," plenary session, ISSCC 2009




Intel Technology Trend




Plastic Transistor

- Electronic paper




-  Semiconductor (Pentacene)
-  Gold Terminals
-  Insulator (Polymer Si/Nx)



Copper Interconnect

- Copper atoms diffuse into the silicon and dielectric, destroying transistors
 - Barrier layers are necessary
- The required process to etch copper wires is tricky
- Copper oxide forms readily and interferes with good contacts
- Care has to be taken not to introduce copper into the environment as pollutant



Copper Damascene Process





- Pros – high conductivity
- Cons – complex process

Capacitors

MIM Capacitor




Fringe Capacitor




Resistor and Inductor


Non-silicide high-resistivity poly resistor



Planar spiral inductor




Memory Category




Non-Volatile Memory (NVM)


- Mask-programmed ROM (read-only memory)
 - Not programmable after manufacture
- One-time programmable (OTP) memory
 - Fuse structured programming flow
- EPROM: electrically programmable ROM
 - Electrical programming, UV erase
- EEPROM: electrically erasable PROM
 - Electrical programmable & erase, byte-level programming
- Flash
 - Block-level programming, faster and cheaper than EEPROM




Flash Memory



BJT in CMOS Process



Cross-Section




Representative Layout

- Used in bandgap voltage reference

Carbon Nanotube (CNT) Transistor

- Better electrical performance than Si but complex process
- Smaller channel length
- Higher speed
- Lower power







Outline

- CMOS Technology
- Layout Design Rules
- CMOS Process Enhancements
- **Technology-related CAD Issues**
- Manufacturing Issues


Design Rule Check (DRC) (I)

- To tolerate non-ideal effects and to guarantee successful device fabrication
- **Ex:** n-well and active region mask alignment error




Design Rule Check (DRC) (II)


- Exposure and etching variation
- **Ex:** different contact windows
→ different contact resistance



alignment rules




resolution rules






Layout vs. Schematic (LVS)

- To ensure layout is the same as *simulated* netlist
 - Check device parameters, interconnects, and I/O ports




Parasitic Extraction (PEX)

- Evaluate RC effects of interconnect (wires)



only C effect




only R effect


Gate Layout

- Layout can be very time-consuming
 - Design gates to fit together nicely
 - Build a library of standard cells
- Standard cell design methodology
 - VDD and GND should abut (standard height)
 - Adjacent gates should satisfy design rules
 - NMOS at bottom and PMOS at top
 - All gates include well and substrate contacts

Example: Inverter




Simplified λ -Based Design Rules




Example: NAND3

- Horizontal n-diffusion and p-diffusion stripes
- Vertical polysilicon gates
- M1 VDD rail at top
- M1 GND rail at bottom
- 32λ by 40λ





Stick Diagrams

- Help to plan layout quickly
 - Need not scale
 - Draw with color pencils or easy-to-erase markers




Wiring Tracks

- Space required by wires
 - 4λ for width and 4λ for spacing = 8λ pitch
- Transistors also consume one wiring track




Well Spacing

- Wells must surround transistors by 6λ
 - Imply 12λ between opposite transistor flavors
 - Leave room for one wire track



Area Estimation

- Estimate area by counting wire tracks
 - Multiply by 8 to express in λ




Example: O3AI (I)

- Sketch a stick diagram for O3AI and estimate area
 - $Y = \overline{(A + B + C)} \cdot D$


Example: O3AI (II)

- Sketch a stick diagram for O3AI and estimate area
 - $Y = \overline{(A + B + C)} \cdot D$



Example: O3AI (III)

- Sketch a stick diagram for O3AI and estimate area
 - $Y = \overline{(A + B + C)} \cdot D$




Outline

- CMOS Technology
- Layout Design Rules
- CMOS Process Enhancements
- Technology-related CAD Issues
- **Manufacturing Issues**



Antenna Rules

- Maximum area of metal connected to gates without discharging element



Density Rules

- CMP and uniform etching process requirement
 - Planarization



- Solution: pattern fill (by CAD)

ref: https://www.eetimes.com/document.asp?doc_id=1276065