

Chapter 10

Design of Feedback Control Systems

10.1 Introduction

- Adjust the system parameters in order to provide the desired system response.
 - If it is not sufficient, we consider the structure of the system and redesign the system in order to obtain a suitable one.
- Design of a control system
 - concerned with the arrangement, or the plan, of the **system structure** and the **selection of suitable components and parameters**.
- Compensation
 - alteration or adjustment of a control system in order to provide a suitable performance

- Compensator (or controller)

→ an additional component that is inserted into a control system to compensate for a deficient performance




FIGURE 10.1

Types of

compensation.

(a) Cascade

compensation.

(b) Feedback

compensation.

(c) Output, or load,

compensation.

(d) Input

compensation.

10.2 Approaches to System Design

- Performance of a control system can be described in terms of
 - time-domain or frequency-domain performance measures
- Time-domain approach
 - specs: peak time, P.O., settling time for a step input; steady-state errors for several test signal inputs and disturbance inputs
 - specs can be defined in terms of the desirable location of the poles and zeros of the closed-loop transfer function
 - a compensator to alter the locus of the roots as the parameter is varied
 - **root locus methods**

- Frequency-domain approach
 - specs: resonant peak and resonant frequency of the closed-loop system, gain margin, phase margin,
 - The design of the compensator is developed in terms of the frequency response as portrayed on the Nyquist plot, the Bode plot, or the Nichols chart.
 - **Bode plot** is preferred because a cascade transfer function is readily accounted for by adding the frequency response of the network

- The design of a system is concerned with the alteration of the frequency response (**Bode plot**) or the **root locus** of the system in order to obtain a suitable system performance.
- When possible, one way to improve the performance of a control system is to alter the process itself.
 - the process is often unalterable or has been altered as much as possible and still results in unsatisfactory performance.
 - addition of compensators becomes imperative for improving the performance of the system.


Assumptions and Outline

- The process has been improved as much as possible and that the $G(s)$ representing the process is unalterable

→ A compensator must be used:

1. Phase-lead design using Bode plot (sec. 10.4)
2. Phase-lead design using root locus (sec. 10.5)
3. Phase-lead design using root locus (sec. 10.7)
4. Phase-lag design using Bode plot (sec. 10.8)

10.3 Cascade Compensators




- Consider the design of a cascade compensator

→ $L(s) = G_c(s)G(s)H(s)$

- Compensator $G_c(s)$ can be chosen to alter either the shape of the root locus or the frequency response

$$G_c(s) = \frac{K \prod_{i=1}^M (s + z_i)}{\prod_{j=1}^n (s + p_j)}$$



- judicious selection of the poles and zeros

- To illustrate the properties, we consider a first-order compensator.

- can then be extended to higher-order compensators, for example, by cascading several first-order compensators


General Design Guideline

- A compensator $G_c(s)$ is used with a process $G(s)$ so that
 1. the overall loop gain can be set to satisfy **the steady-state error** requirement
 2. the system dynamics can **be adjusted favorably without affecting the steady-state error**

Phase-Lead Compensator

$$G_c(s) = \frac{K(s + z)}{s + p}$$


- $|Z| < |P|$



- $|Z| \ll |P|$

→ A differentiator

$$G_c(s) \approx \frac{K}{p}s.$$




$$G_c(s) = \frac{K(1 + \alpha\tau s)}{\alpha(1 + \tau s)},$$

$$\omega_m = \sqrt{zp} = \frac{1}{\tau\sqrt{\alpha}}$$

$\tau = 1/p$ and $p = \alpha z$ (or $\alpha = p/z > 1$)


Physical constraint: maximum phase angle $< 70^\circ$

What if a larger angle is required?



Phase-Lag Compensator

- $|Z| > |P|$




$$G_c(s) = K\alpha \frac{1 + \tau s}{1 + \alpha\tau s}$$

$\tau = 1/z$ and $\alpha = z/p > 1$.

Note:

$\alpha = p/z$ for phase-lead compensator

$\alpha = z/p$ for phase-lag compensator



Purposes of Phase-Lead and Phase-Lag Compensators

- Phase-lead Compensation
 - 1) Reshape the root locus (root locus)
 - 2) Add a phase margin (Bode diagram)
- Phase-lag Compensation (not to provide a phase-lag angle)
 - 1) Reduce the steady-state error (or increase the error constant) without affecting the root locus (Root locus method)
 - 2) Add a phase margin (Bode diagram) **how?**

Provide an attenuation!

Videos helpful for understanding control system designs

What are Lead Lag Compensators? An Introduction.

<https://www.youtube.com/watch?v=vXwOzDs5xKY&list=PLUMWjy5jgHK1NC52DXXrriwihVrYZKqjk&index=33>

- Designing a Lead Compensator with Root Locus

<https://www.youtube.com/watch?v=vXwOzDs5xKY&list=PLUMWjy5jgHK1NC52DXXrriwihVrYZKqjk&index=34>

- Designing a Lead Compensator with Bode Plot

<https://www.youtube.com/watch?v=vXwOzDs5xKY&list=PLUMWjy5jgHK1NC52DXXrriwihVrYZKqjk&index=35>

- Designing a Lag Compensator with Root Locus

<https://www.youtube.com/watch?v=vXwOzDs5xKY&list=PLUMWjy5jgHK1NC52DXXrriwihVrYZKqjk&index=36>

- Designing a Lag Compensator with Bode Plot

<https://www.youtube.com/watch?v=vXwOzDs5xKY&list=PLUMWjy5jgHK1NC52DXXrriwihVrYZKqjk&index=37>

Phase-Lead Compensation

- Reshape the root locus (root locus method)

$$L(s) = K \left(\frac{s + z}{s + p} \right) G(s) = G_c(s)G(s) \quad (1)$$

- a) Increase the system type to address the steady-state error (or error constants) if necessary.
- b) Place z to the left of the rst two real poles of $G(s)$.
- c) Select p to the left of z .
- d) Evaluate $K = f(p, z)$ where f represents the relationship that meets the requirement on the error constant if any; otherwise, choose K to meet the specs.

$$\zeta \approx 0.01\phi_{pm} \text{ for } \zeta \leq 0.7 \text{ and } \phi_{pm} \text{ in degrees.}$$

Phase-Lead Compensation

- Add a phase margin (Bode diagram method)

$$L(s) = K \frac{p}{z} \left(\frac{s + z}{s + p} \right) G(s) = G_c(s) G(s) \quad (2)$$

- a) Increase the system type to address the steady-state error (or error constants) if necessary.
- b) Select loop gain K to meet the steady-state error (or error constants);
- c) Select phase. center ω_m
- d) Select phase $\phi_m < 70^\circ$ to be added.
- e) Evaluate $\alpha = (1 + \sin(\phi_m)) / (1 - \sin(\phi_m))$, $p = \omega_m \alpha^{0.5}$, and $z = p / \alpha$.

Note: $\sin(\cdot)$ only accepts angles in radians in Matlab.

Phase-Lag Compensation

- Reduce the steady-state error (or increase the error constant) without affecting the root locus (Root locus method) where the loop transfer function is defined in (1).
 - a) Determine the loop gain K to meet the specs, excluding the one for the error constant.
 - b) Determine the pole--zero ratio $\alpha = z/p$ to achieve the error constant.
 - c) Place z close to origin so that the shape of the root locus is only changed slightly.
 - d) Evaluate $p = \frac{z}{\alpha}$.

Phase-Lag Compensation

- Add a phase margin (Bode diagram method) where loop transfer function is defined in (2).
 - a) Select loop gain K to meet requirements of the steady-state error or error constant.
 - b) Select the new gain crossover frequency ω_c that results in the desired
 - c) Determine the corresponding attenuation M dB in gain to make ω_c the new crossover frequency.
 - d) Evaluate $z = \omega_c/10$, $\alpha = 10^{M/20}$, and $p = z/\alpha$.